

WORKSHOP #1: MONITORING PARROTS AND OTHER WILDLIFE IN SVG: PASSIVE ACOUSTIC MONITORING

Cristina M Gomes, PhD
Vijay Ramesh, PhD






06. AUDIOMOTH CONFIGURATION & DATA MANAGEMENT

WHAT DO I NEED BEFORE I START?

- Computer
- 3 AA Batteries
- Micro SD card (memory card)
- Micro USB cable
- AudioMoth audio recorder



EXTRA STEP: NEED TO DO IT ONLY ONCE!

- Download the AudioMoth Flash App on your computer from this link and install it:
<https://www.openacousticdevices.info/applications>
- Connect your recorder using the USB cable to the computer. You will notice a **GREEN** light!
- *Do not include the batteries or the memory card in this process*
- Open the App
- Click **Flash AudioMoth**

**CONGRATULATIONS! YOU JUST UPDATED THE
FIRMWARE ON THE RECORDER**

NOW, WE CAN CONFIGURE IT!



HAVE YOU ALREADY USED THE FLASH APP? IF YES, PROCEED!

NO? Go back and complete that step


MEMORY CARD FORMATTING

- Insert the SD card into your laptop (use a card adaptor if needed)






Confirm
that you
are
formatting
to FAT32




I WAS NOT ABLE TO FORMAT MY MEMORY CARD. WHAT DO I DO?

- Download the software guiformat.exe from <http://ridgecrop.co.uk/index.htm?guiformat.htm>
- Insert the microSD card into the laptop/computer
- Open the program guiformat.exe
- Choose the Drive that belongs to the SD card from the drop-down menu
- Select Allocation Unit Size as 32768
- Select Quick Format > Start




If you get an error like the one below, please close all files that are open on your computer and restart this program!



INSERT BATTERIES AND MEMORY CARD INTO YOUR RECORDER

- Add 3 AA batteries to the AudioMoth
- Insert the microSD card to your recorder




BEFORE WE CONFIGURE THE RECORDER...

- Download the AudioMoth configuration App on your laptop/computer from the link below and install it
- <https://www.openacousticdevices.info/applications>

FINALLY...WE CAN CONFIGURE OUR RECORDER!

- Make sure your AudioMoth recorder's white button on the side is pointing to **USB/OFF**
- Connect the recorder (make sure you have included batteries and the memory card) to the laptop/computer with the USB cable. You will notice a **Green** light!
- Open the configuration app



The screenshot shows the 'AudioMoth Configuration App' window. At the top is a menu bar with 'File', 'Process', 'Time', and 'Help'. Below the menu is a large text input field for a date and time, currently showing '--:--:-- --/--/---- UTC'. Underneath is a section for device information with labels 'Device ID:', 'Firmware description:', 'Firmware version:', and 'Battery:', each followed by a hyphen. A tabbed interface follows, with 'Recording' selected and others being 'Schedule', 'Filtering', and 'Advanced'. The 'Recording' tab contains several settings: 'Sample rate (kHz)' with radio buttons for 8, 16, 32, 48 (selected), 96, 192, 250, and 384; 'Gain' with radio buttons for Low, Med (selected), and High; 'Enable sleep/record cyclic recording' with a checked checkbox; 'Sleep duration (hh:mm:ss)' with a time picker set to 00:00:5; and 'Recording duration (hh:mm:ss)' with a time picker set to 00:00:55. Below these are three more checkboxes: 'Enable LED' (checked), 'Enable battery level indication' (checked), and 'Use NiMH/LiPo voltage range for battery level indication' (unchecked). At the bottom of the configuration area, a message states: 'Each day this will produce 0 files, totalling 0 MB. Daily energy consumption will be approximately 0 mAh.' A large green button at the very bottom is labeled 'Configure AudioMoth'.

QUICK WAY TO CONFIGURE:

- Click Time → Local time
- Do you see **UTC-4**?
- Is your battery voltage above 4.5V? (*If not, use another battery*)
- *Note down the Device ID in your **deployment-data.csv** file (for more information, please see section on Data Management)*
- Click File → Open configuration → *select the **stVincent-parrot.config** file from your folder*
- Click **Configure AudioMoth** in green

**CONGRATULATIONS! YOUR RECORDER IS READY
FOR DEPLOYMENT**

**IF YOU WANT TO LEARN THE LONGER WAY TO CONFIGURE YOUR
RECORDER.....**

AudioMoth Configuration App

File Process Time Help

--:--:-- --/--/---- UTC

Device ID: -
Firmware description: -
Firmware version: -
Battery: -

Recording Schedule Filtering Advanced

Sample rate (kHz): 8 16 32 48 96 192 250 384
☐ ☐ ☐ ☒ ☐ ☐ ☐ ☐

Gain: Low Med High
☐ ☐ ☒ ☐

Enable sleep/record cyclic recording: ☒

Sleep duration (hh:mm:ss): 00:00:05

Recording duration (hh:mm:ss): 00:00:55

Enable LED: ☒
Enable battery level indication: ☒
Use NiMH/LiPo voltage range for battery level indication: ☐

Each day this will produce 0 files, totalling 0 MB.
Daily energy consumption will be approximately 0 mAh.

Configure AudioMoth

- Click Time → Local time
- Do you see **UTC-4**?
- Is your battery voltage above 4.5V? (*If not, use another battery*)
- *Note down the Device ID in your **deployment-data.csv** file (for more information, please see section on Data Management)*


RECORDER SETTINGS: SAMPLE RATE

- Sample rate refers to the number of audio samples recorded every second by the recorder.
- Sampling rate must be $\geq 2X$ the highest frequency you want to record

RECORDER SETTINGS: GAIN

- Gain refers to the amount of amplification applied to a signal before it is digitized and stored


Appropriate gain



Too little gain... lower quality



Too much gain... clipping



RECORDING SCHEDULE FOR THE ST. VINCENT'S PARROT

- Select Sample rate as **32kHz**
- Select **Medium** gain
- Select Sleep duration:
- Select Recording duration:

This means that the recorder will collect data for every XX minutes and sleep for every YY minutes

Click the box next to 'Use NiMH/LiPo...' if you are using rechargeable batteries

Recording schedule for the St. Vincent's parrot

- Click on the **Schedule** tab (*right next to the Recording tab*)
- Add start recording as 04:00 and end recording as 07:00; Click **Add recording period**
- We will also add start recording as 11:00 and end recording as 14:00; Click **Add recording period**
- We will also add start recording as 16:00 and end recording as 19:00; Click **Add recording period**

Now we have created three different schedules and the recorder will collect data once in the morning, afternoon and evening

ADVANCED SETTINGS

- Click on the **Advanced** tab
- Mark the box next to 'Use daily folder for generated WAV files'
- Mark the box next to 'Enable energy saver mode'

Click **Configure AudioMoth** in green

LET'S DEPLOY THE RECORDER!

DATA MANAGEMENT

- Data organization
- Data storage

DATA ORGANIZATION

- Data organization allows for easy access and interpretation of data
- To organize data, we need standardized ways in which data is organized or collected.
- Example: a **unique** format for filenames, latitude, longitude etc.

**THIS SLIDE WILL REFER TO INFORMATION FROM KOBOCOLLECT
(VIJAY TO EDIT IT)**

HOW DO WE ORGANIZE AND MANAGE OUR DATA?



FIRST WE WILL MAKE COPIES OF YOUR DATA!

- The field is often not the best place to back up data
- Make back-up copies in an environment that where you can ensure the safe transfer of data
- Always make two copies before deleting or reusing media



STEP 2: MAKING THE COPIES IN HARD DRIVES

- Connect the SD card using an adaptor
- For example, let's assume this SD card corresponds to XXYY_site_YY
- Create a folder with the same name in hard drive 1
- Repeat the above for hard drive 2
- Vijay to add information about deployment cycle and naming hard drives



CHECK THAT ALL DATA WERE COPIED OVER

- Do not assume that computers and drives and networks always make perfect copies.
- Copy jobs can easily be interrupted
- Check that both folders are the same size and have the same number of files







YOU HAVE RETRIEVED YOUR RECORDER....WHAT DOES YOUR DATA LOOK LIKE?

WHEN YOU LOAD YOUR SD CARD IN YOUR COMPUTER...THIS IS WHAT YOU WILL SEE

20240121

20240120



	20240120_183000	1/20/2024 8:05 AM	WAV File	18,751 KB
	20240120_193000	1/20/2024 9:05 AM	WAV File	18,751 KB
	20240120_203000	1/20/2024 10:05 AM	WAV File	18,751 KB
	20240120_213000	1/20/2024 11:05 AM	WAV File	18,751 KB
	20240120_223000	1/20/2024 12:05 PM	WAV File	18,751 KB
	20240120_233000	1/20/2024 1:05 PM	WAV File	18,751 KB

Each SD card will have folders of audio files.
Each folder contains data for a single day of recording

Within each of those folders, you will data for that particular day

THANK YOU!



K. Lisa Yang Center for Conservation Bioacoustics