How do I find a waypoint, create a new waypoint and delete a waypoint using the GPS?

1. Press the Power button on the side of the GPS to switch it ON



2. Press the MENU button two times to see the Main Menu



3. Press the UP or DOWN arrows until you see SATELLITES. Now, press ENTER.



- 4. Make sure that GNSS shows less than **5 metres**. This means that the GPS has picked up all the SATELLITES for your work.
- 5. Press the MENU button two times until you see the MAIN MENU now.



6. Go to WAYPOINT MANAGER and press ENTER. Now, find the Survey Point that you are planning to go to. For example, this could be PO19 or PO20 (Below, you will see an example of different waypoints in your GPS).



7. Click on the Survey Point number that you need to navigate to by pressing ENTER. Click the GO button at the bottom.

8. Press the QUIT button three times to find the compass page like this below.



- 9. Now walk to the point you need to navigate to. If this is the FIRST TIME you are navigating to the location and you need to find a tree to DEPLOY the AudioMoth, choose an appropriate location that is within 50 metres of the point. IT DOES NOT HAVE TO BE THE EXACT SAME POINT.
- 10. If you are deploying a recorder for the first time at this location and you need to create a new WAYPOINT at this location. Click on the MARK button and you will see this image.



11. Use the UP and DOWN arrows to change the NAME of the Waypoint to the "Survey Point Number" followed by "Location". For example, this could be PO19MONTREAL or PO20MAJORCA. Press ENTER when you are done.

- 12. Remember to also press DONE after you have recorded the latitude, longitude and elevation in KoboCollect. THIS IS IMPORTANT! **Your new WAYPOINT will get saved only after you press DONE.**
- 13. If this is the first time you are deploying a recorder and you have saved a new WAYPOINT, you can DELETE the OLD WAYPOINT. Click on the OLD WAYPOINT by pressing ENTER. *Remember, all old waypoints do not have location information*. They will be called PO1 or PO2. The new waypoints will be called PO1FANCY for example.
- 14. Now press the MENU button and press Delete. **BE VERY CAREFUL** make sure you are only deleting the old Waypoint.



Congratulations! You have successfully navigated to a waypoint, created a waypoint and deleted an old waypoint.